

## MINDER Mini PIR Alarm with Keypad



## **Description**

The MINDER Mini PIR Alarm features a 120dB alarm siren which sounds when the PIR motion detector is activated. It has two operating modes - alarm and chime; alarm mode will sound a continuous alarm when activated, whereas the chime mode will sound a door chime. The alarm is easily operated by a 4 digit code using the keypad on the front of the device and is suitable for use either free standing or wall mounted, with wall mounting fixture included. It has a detection distance of 6m and recommended installation height of 1.8m.

## **Features**

- Suitable for use freestanding or wall mounted
- 120dB alarm siren
- Keypad control to allow safe entry/exit for the user
- 4 digit access code
- Alarm and chime operating modes

## **Product Table**



L31357

White