

Features

- LED Indicator: Displays keypad status
- Numeric Keys: Used for entering user codes
- Arm Key: Press for Away Arming
- Panic Keys A and B: Press both for Panic alarm
- Home Arm Key: Press to partially arm
- Disarm Key: Used with user code to switch system off or to silence alarm

Product Table



L22077

15 Button